



Submarine Harren

Operation & Maintenance Manual





Table of Contents


1. Fundamental knowledge(submarines)
2. Specification
3. Construction
4. Ballast system
5. Drivetrain, Diesel-electric system
6. Electric gadgets
7. Lift and transport
8. How to operate
9. Life support and bailout
10. Maintenance

1. Fundamental knowledge


“It’s all about buoyancy”



Pressure




Surface(1ATM)	1 bar
10m	2 bar
20m	3 bar
30m	4 bar
40m	5 bar
50m	6 bar




2. Specification

- Built between 2014-2018 By Martin Hedin
- Design depth 50m
- Operational depth 20m(test dive to 20m)
- Length 6.2m
- Width outside 1.1m
- Total Width(trim rudder) 1.6m
- Internal width 0.8m
- Height(WO periscope) 1.55m
- Total height 2.8m
- Weight 2700kg
- Operational distance electric 15km cruise speed.
- Operational distance diesel ?



- Hull thickness 5mm
- Material hull. mild steel
- Material bushings. Brass
- Material shafts, Stainless EN1.4404
- Paint. Epoxy
- Windows. Acrylic

3. Construction




1. Pressurehull(Cabin)
2. Bow ballast tank 470l
3. Stern ballast tank 370l
4. External weight 800kg


4. Ballast System

“Air to pump out water”

1. Primary LP tanks(8 bar)
2. Secondary HP tanks(200 bar)
3. Ballast tank



P&ID Ballast system



Secondary HP tanks(200 bar) "regulators"



Ballast relief valve stern

"Outside hull"



Ballast relief valve bow

”Outside hull”




Ballast blow valves

"Inside hull"




5. Drivetrain





The submarine have 5kW electric motor for propulsion mainly. It also has a 5,5hp diesel engine for surface transport. Both are conected with drivebelts to propeller shaft. The diesel engine has a centrifugal clutch so it only works on high rev.

5kW BLDC 48v Motor

GOLDENMOTOR Sine Wave Controllers wiring harness diagram



5.5hp Diesel




7. Lift and transport






- Equipped with a trailer
- Be sure to fasten the vessel as shown on picture(tight)
- Only use the trailer short distance
- Trailer is built for slow speed
- Trailer is custom built for the vessel
- Be sure to place the vessel so the weight don't get to high on the towbar. Aligning markings on sub and trailer.






- Always use approved lifting equipment
- Attach only to the lifting hoist
- Do not add weight to the submarine
- Stay out of the way when lifting





- Straps angle max 30°




Always check for leaks or bubbles before releasing the straps. If leaks are detected when launching, immediately lift the vessel up from water and inspect, replace or repair faulty parts before launching again.

NEVER DO ANY REPARATION WHEN VESSEL IS SET TO SEA!



8. How to operate







Operate a submarine is not the easiest thing in the world. It takes time to understand how the system works and the laws of physics that comes with it. NEVER TRY TO OPERATE THE SUBMARINE WITHOUT PROPER TRAINING. COULD RESULT IN EMIDIATE DEATH.

This chapter is a guide to learn to know the sub and its system to be able to operate it responsible and safe.


“Checklist it’s easy to forget”




Preparation step by step




Set to sea step by step




Using diesel engine, step by step






Dive, step by step

Never dive if depth exceeds operational depth!






10. Maintenance


- Battery removal
- Engine removal
- Motor removal
- Compressor removal
- Oil and lubrication
- Through hull sealing assembly

Battery removal, step by step



1. Remove oxygen tank
2. Remove bailout tank
3. Remove battery top cover nuts(4x M8) and bolts holding the chargers.

Battery removal, step by step



1. Remove rubber isolation(protect from short Circuit)

Battery removal, step by step

“Short circuit could lead to fire and massive danger”



1. Shut of main switch
2. De attach charger cables.
3. De attach ground cables one by one. Be sure to isolate them.
4. De attach +cables one by one, be sure to isolate them one by one.


Battery removal, step by step

Batteries are heavy, dont hurt your back 😊



- Remove batteries one by one.

Engine removal, step by step




1. Remove batteries(previus step)
2. Remove throttle cable
3. Remove exhaust
4. Remove belt
5. Remove wiring
6. Remove engine(4x M8)




Battery removal, step by step



1. Remove batteries(prevuis step)
2. Remove engine(previus step).
3. Remove drivebelts
4. Remove sprockets
5. Remove motor bolts and bracket(6xM10).






Compressor removal, step by step



1. Remove batteries
2. Remove engine
3. Release pressure(main tanks)
4. Remove pressure hose.
5. Remove drive belt.
6. Remove bolts(4xM10)

Oil and lubrication

1. Propeller shaft oil (Redline shockproof synthetic gear oil)
2. Compressor oil ("Compoil" SEA30)
3. Engine oil (Shell 10W-40)



Through hull sealing assembly



The sealing system consists of precision made parts, orings and hydraulic seals.

Hydraulic seals need to be replaced after 3 years of service or when leaking.

Through hull sealing assembly

The sealing system consists of precision made parts, o-rings and hydraulic seals.

Hydraulic seals need to be replaced after 3 years of service or when starts leaking.

